



**MMPO**

Stand Brkt 48383-9000  
Standard Location  
49933-1702  
w/ 1/4-20 studs




**MMPA**

Stand Brkt 48383-9000  
Top & Bottom  
49933-




**MMPB**

Stand Brkt 48383-9000  
Top Inverted  
49933-1730




**MMPC**

ABB Brkt 48383-9009  
Bottom  
49933-1910  
w/ 1/4-20 studs




**MMPD**

Stand Brkt 48383-9000  
Top  
49933-1920




**MMPE**

Stand Brkt 48383-9000  
Bottom  
49933-1951




**MMPF**

ABB Brkt 48383-9009  
Top & Bottom  
49933-1968



**MMPG**

Stand Brkt 48383-9000  
Standard Location  
ABB Brkt 48383-9009  
Bottom  
w/ 1/4-20 studs



*MMPS*

*Special Locations*

15.63" Mounting Centers Std Brkt  
16.00" Mounting Centers ABB Brkt